

Kodak play touch

Video Camera



Specifications

Sensor type	1/3.2-type, 5 MP CMOS
Lens	3.9 mm 35 mm equivalent 44 mm @ 1080p without DIS 33 mm @ 720p without DIS 33 mm @ WVGA without DIS 33 mm @ still capture
Zoom	4X digital
Image stabilization	Digital
Display	3.0 type capacitive touchscreen LCD
Storage	128 MB internal memory*; SD/SDHC card expansion slot (up to 32 GB card)
Focus modes	Normal, macro
Focus range	Normal: 100 cm - infinity; macro: 15 cm
White balance	Auto
File format	Video: MPEG-4, AAC LC Still: JPEG
Capture modes	1080p (1920 x 1080, 30 fps) 720p /60 fps (1280 x 720, 60 fps) 720p (1280 x 720, 30 fps) WVGA (848 x 480, 30 fps) Still (5.3 MP, 16:9 widescreen, interpolated)
Capture effects	Normal (default), sepia, black and white, high saturation, 70's film look
Microphone	Yes (monaural)
Speaker	Yes
I/O interface	USB 2.0 (high-speed), AV out, HDMI, external stereo mic/headphone jack
Tripod mount	1/4" standard
Power	KODAK Li-Ion Rechargeable Digital Camera Battery KLIC-7004, AC adapter
Dimensions	5.9 x 11.0 x 1.6 cm (2.3" x 4.3" x 0.6")
Weight	100 g (3.5 oz.) without batteries
Warranty	One year

Package contents

- KODAK PLAYTOUCH Video Camera
- KODAK Li-Ion Rechargeable Digital Camera Battery KLIC-7004
- Adapter and cable for battery charging
- HDMI and AV cables
- Wrist strap
- Quick Start Guide
- ARCSOFT MEDIAIMPRESSION Software for Kodak (on-camera, PC only)

Minimum system requirements

WINDOWS WINDOWS XP SP2, VISTA, WINDOWS 7 or later, INTERNET EXPLORER 6.0 or higher, PENTIUM-4 2.8GHZ processor or higher

MACINTOSH MACINTOSH 10.4, 10.5, 10.6 or higher

Minimum hardware requirements

1 GB RAM and 64 MB video RAM, 1024 x 768 display resolution, 300 MB available hard drive space, USB v1.1 or higher

For smooth HD video playback, faster processor required. Go to www.kodak.com/go/hdsysreq for details.

Recommended accessories

KODAK SDHC Video Memory Card, 16 GB	CAT 156 1679
KODAK SDHC Video Memory Card, 8 GB	CAT 135 7441
KODAK Li-Ion Rechargeable Digital Camera Battery KLIC-7004	CAT 192 4059
KODAK Camera Battery Charger K7700	CAT xxx xxxx
KODAK Device Case	CAT 104 7398
KODAK Remote Control	CAT 140 2486
KODAK HDMI Cable / Model HDMI-2	CAT 820 1600

*128 MB internal memory/20 MB available for video and picture storage (1 MB equals one million bytes).

For more information on the KODAK PLAYTOUCH Video Camera, visit www.kodak.com/go/videocameras



© Kodak, 2010. KODAK, PLAYTOUCH, KODAK MOMENT, and IT'S TIME TO SMILE are trademarks of Kodak. Product specifications subject to change without prior notice. Simulated images. IC-xxxx CAT No. xxx-xxxx

Kodak it's time to smile™